

Tele Feeder	Insert
CB 31-21 Tele 40-15 (26)	EK 40 / 70 SZP
CB 31-21 Tele 80-17 (28)	EK 50 / 80 SZP
CB 31-21 Tele 80-18 (34)	EK 50 / 80 SZP
CB 21-21 Tele 90-18 (34)	EK 50 / 100 SZP
CB 31-21 Tele 100-18 (35)	EK 60 / 90 SZP
CB 31-21 Tele 160-18 (35)	EK 60 / 110 SZP
CB 31-21 Tele 160-25 (40)	
CB 43-21 Tele 195-22 (38)	EK 70 / 100 SZP
CB 21-21 Tele 220-25 (40)	EK 80 / 110 SZP
CB 21-21 Tele 290-30 (52)	EK 100 / 110 SZP
CB 21-21 Tele 290-40 (70)	
CB 21-21 Tele 300-30 (52)	EK 100 / 130 SZP
CB 21-21 Tele 300-40 (70)	
CB 21-21 Tele 500-40 (62)	EK 120 / 110 SZP
CB 21-21 Tele 500-60 (80)	
CB 21-21 Tele 700-30 (52)	EK 100 / 170 SZP
CB 21-21 Tele 700-40 (70)	
CB 111-21 Tele 710-45/20	CD ov 950 SZP
CB 21-21 Tele 850-45 (20)	
CB 21-21 Tele 850-60 (80)	EK 120 / 150 SZP
CB 21-21 Tele 960-40 (70)	CD 1100 SZP
CB 21-21 Tele 1100-60 (80)	CD 1380 SZP

<b>Tele Feeder</b>	<b>Insert</b>
<b>CB 22-21 Tele 10-10 (24)</b>	CD 25 SZP
<b>CB 22-21 Tele 12-15 (24)</b>	CD 27 SZP
<b>CB 22-21 Tele 24-15 (24)</b>	CD 37 SZP
<b>CB 31-21 Tele 100-25 (40)</b>	EK 60 / 90 SZP
<b>CB 31-21 Tele 120-25 (40)</b>	EK 70 / 100 DF SZP
<b>CB 43-21 Tele 125-32/14</b>	CD ov 127 SZP
<b>CB 31-21 Tele 180-25 (40)</b>	EK 60 / 120 SZP
<b>CB 43-21 Tele 190-30 (46)</b>	EK 90 / 63
<b>CB 43-21 Tele 210-30/20</b>	CD ov 280 SZP
<b>CB 43-21 Tele 320-30/20</b>	CD ov 360 SZP
<b>CB 21-21 Tele 330-30 (52)</b>	EK 100 / 75
<b>CB 21-21 Tele 500-40 (62)</b>	EK 120 / 110 SZP
<b>CB 21-21 Tele 820-40 (70)</b>	CD 1007
<b>CB 21-21 Tele 1200-40 (62)</b>	EK 120 / 200
<b>CB 21-21 Tele 1200-60 (80)</b>	EK 120 / 200
<b>CB 21-21 Tele 1200-70 (98)</b>	EK 120 / 200
<b>CB 111-21 Tele 1600-60 (98)</b>	CD 1800 SZP
<b>CB 111-21 Tele 2000-45 (20)</b>	CD 2100 SZP
<b>CB 111-21 Tele 2000-70 (98)</b>	CD 2100 SZP
<b>CB 111-21 Tele 3600-65 (100)</b>	CD 4100 SZP
<b>CB 111-21 Tele 5300-165/200</b>	CD ov 5900 SZP